

Congratulations on your purchase of **Zoo Med's REPTICARE DAY/NIGHT Timer**. The following instructions and safety information will assist you with the proper programming, set-up, and safe use of this timer.

IMPORTANT SAFETY NOTICE!

To reduce the risk of fire, injury, or electric shock, read and follow these instructions prior to operating this device. Save these instructions for future reference.

SAFETY INSTRUCTIONS:

- Carefully examine your new timer and inspect for damage. If damage is present, do not use the timer. If damage is suspected, contact Zoo Med's customer service department.
- Caution must be taken when using electrical appliances near water (e.g. Aquatic turtle habitats or tanks with other aquatic species). To reduce the risk of electric shock, be sure that this timer is unplugged during any of the following situations:
 - Unplug when performing aquatic habitat maintenance.
 - Unplug before placing your hand(s) in the water of the aquatic habitat.
 - Be sure that your hands are completely dry before plugging a lamp fixture or other device into the timer.
 - Unplug if the timer comes into direct contact with water, or if any part of the lamp fixture or other device being controlled by the timer becomes wet.
 - Unplug when not in use.
- When unplugging the lamp fixture or other device from the timer, grasp the plug to prevent damage to the power cord. Never pull on the power cord to unplug the device.
- DO NOT exceed electrical rating. This timer is rated for 8 Amps/900 Watts.
- DO NOT attempt to modify this timer in any way. This timer has no user serviceable parts. Inspect the timer periodically for damage.
- This timer is intended to control two devices only. The use of power taps and splitters to control additional devices is not recommended and may create an unsafe condition.
- For indoor use only.
- For terrarium use only.

PROGRAMMING and OPERATION of YOUR TIMER:



• • DAYTIME SETTING:

Tabs down to control daytime lamp plugged into <u>---</u> top outlet.

- • NIGHTTIME SETTING:

lamp to be on.

Tabs up to control nighttime lamp or heater plugged into – bottom outlet.

• SETTING THE TIME OF DAY: The arrow on the face of the timer indicates the time of day. To set the time, rotate the dial until the arrow is pointing at the correct time. This timer will only operate when plugged in. In the event of a power outage, the time of day will need to be reset.



NO

• SET THE RED BYPASS SWITCH TO TIMER: To enable the day/night timer function, be sure to slide the red switch on the side of the timer down toward the timer icon ①. To bypass the timer and manually turn on the daytime lamp, slide the switch up to the "on" setting (only top outlet will remain on, bottom outlet will be off). Push it back down to the timer setting to resume normal timer function.

NOTES FOR USE WITH AQUATIC HABITATS:

Φ PLUG THE TIMER INTO A GROUNDED GFCI (Ground Fault Interrupted Circuit) OUTLET: To reduce the risk of electric shock, this timer has a three-prong plug and must be plugged into a grounded three-prong receptacle. If using this timer near aquatic habitats (e.g. Aquatic turtle habitats or tanks with other aquatic species), the receptacle must also be GFCI protected. If you are unsure about the electrical supply and connection, contact a qualified licensed electrician. See figure 1. (figure 1) **DRIP LOOP:** If using near an aquatic habitat, the appliances Grounded plugged into this timer must incorporate a "drip loop". The drip **3 Pronged Plug** loop will prevent water from running along the power cords and getting the and **GFCI** Receptacle timer outlet or wall receptacle wet. To create a drip loop, be sure that a Φ portion of each power cord is lower than the level of the wall receptacle as **shown in figure 2.** If for any reason the plug or wall receptacle gets wet, do not grasp or unplug the power cord until after the power has been switched off at the main fuse or circuit breaker. (figure 2) **Drip Loop** GFCI

WARRANTY:

Zoo Med Laboratories, Inc. (Zoo Med) warrants this product to be free of defects in material and workmanship under normal use and service for one year from the date of purchase. The obligation under this warranty is limited to the repair or replacement, at Zoo Med's discretion, of the product or any part thereof, when the product is returned to Zoo Med, freight prepaid. No claim shall be allowed under this warranty if, in the opinion of Zoo Med, this product has been subject to accident or improper usage, including but not limited to: water damage, improper storage, accidental dropping, etc. This warranty is in lieu of all other warranties and representations express or implied. Please include your receipt, full name, address, phone number, and email address along with a note explaining failure when sending any product back to Zoo Med. Please allow 4 to 6 weeks for repair or replacement.

ZOO MED LABORATORIES, INC. 3650 Sacramento Dr. • San Luis Obispo, CA 93401 U.S.A. • Phone: 805-542-9988 • E-mail: zoomed@zoomed.com

www.zoomed.com