



# 36" KIDS MINI TRAMPOLINE WITH HANDRAIL

MODEL# 9006KM

PRODUCT MANUAL - VERSION 01.18.04

FOR AGES:

**3-7**

WEIGHT LIMIT:

**75** Lbs  
35 Kgs

ADULT(S) NEEDED:




TOOLS NEEDED:




## WARNING/ADVERTENCIA


- Consult a physician before beginning any exercise program or strenuous activity.
- Do not allow more than one person on this product at any time.
- Children must be supervised by an adult at all times.
- Not recommended for children under 3 years of age.
- The contents of this package are not suitable for children under 3 years of age. Contains small parts which may cause choking.
- ADULT ASSEMBLY REQUIRED.

## CUSTOMER SERVICE

 GQBrands.com

 Customerservice@gqbrands.com

 1-866-498-5269

 4401 Samuell Blvd, Ste 150  
Mesquite, TX 75149

# CUSTOMER SERVICE INFORMATION

---

Thank you for purchasing:

## 36" KIDS MINI TRAMPOLINE WITH HANDRAIL

MODEL# 9006KM

At Global Quality Brands®, we want all of our customers to be completely satisfied with their purchase. Please take time to review the contents of the product you have just received to make sure that all of the parts are included. If you find that any parts are missing or damaged, we will happily provide replacement parts at no charge within 30 days of purchase.

Please keep in mind that for select damaged part replacement requests, we will require a photo for submission.

If you request replacement parts, please be sure to include the following information in your correspondence:

To order these parts, or if you have any other questions or concerns about this GQ Brands product, please contact us at

PureFun.net  
Global Quality Brands®  
Phone: 1-866-498-5269  
Email: customerservice@gqbrands.com  
4401 Samuell Blvd, Ste 150  
Mesquite, TX 75149

**Sincerely,**  
Customer Service

**YOUR NAME:**

**YOUR MAILING ADDRESS:**

**YOUR EMAIL ADDRESS:**

**PRODUCT NAME:**

**PRODUCT MODEL #:**

**PART #** (Located In Manual)

**RETAILER WHERE YOU PURCHASED PRODUCT:**

**DATE OF PURCHASE:**

**ORDER #** (If Available)

**SERIAL#:**

**QUANTITY NEEDED:**

**PICTURE OF DAMAGED PART(s)** SUBMIT VIA Email, Fax, or Mail

# LIMITED WARRANTY

---

Global Quality Brands® warrants this product to be free from defects in workmanship and materials under normal use and conditions for a period of 90 DAYS FROM THE DATE OF ORIGINAL PURCHASE. This Limited Warranty is not transferable and is available only for the original purchaser of the Product. The Company's obligation under this warranty is limited to replacing or repairing the Product, at the discretion of the company.

All warranty coverage extends only to the original retail purchaser from the date of purchase, GQ Brands obligation under this warranty is limited to replacing or repairing, at Global Quality Brands® option. All products for which a warranty claim is made must be received by Global Quality Brands® and accompanied by sufficient proof of purchase (photocopy of the original store receipt, indicating the date of purchase). All freight and handling fees are the responsibility of the consumer to pay, both to and from Global Quality Brands®. All warranty claims must be preauthorized by Global Quality Brands® pre-authorization can be obtained by calling 866-498-5269.

This warranty does not cover ordinary wear and tear, weathering, failure to follow directions, improper installation, improper maintenance, or acts of nature, (such as damage caused by wind, lightning, snow, water, or ice) weather damage, damage caused by unauthorized repair work or damage caused by improper use of the products are not covered by the product warranty. No other warranty beyond that specifically set forth above is authorized by GQBrands®.

GLOBAL QUALITY BRANDS® IS NOT RESPONSIBLE OR LIABLE FOR INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT OR OTHER DAMAGES WITH RESPECT TO ANY ECONOMIC LOSS, LOSS OF PROPERTY, LOSS OF REVENUE OR PROFITS, LOSS OF ENJOYMENT OR USE, COST OF REMOVAL, INSTALLATION OR OTHER CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THE WARRANTY EXTENDED HEREUNDER IS IN LIEU OF ALL OTHER WARRANTIES AND GLOBAL QUALITY BRANDS®, SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS SCOPE AND DURATION TO THE TERMS SET FORTH HEREIN. SOME STATES DO NOT ALLOW LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS. ACCORDINGLY, THE ABOVE LIMITATION MAY NO APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

WHILE EVERY ATTEMPT IS MADE TO ENSURE THE HIGHEST DEGREE OF PROTECTION IN ALL EQUIPMENT, WE CANNOT GUARANTEE FREEDOM OF INJURY. THE USER ASSUMES ALL RISK OF INJURY DUE TO USE. ALL MERCHANDISE IS SOLD ON THIS CONDITION, WHICH NO REPRESENTATIVE OF GQ BRANDS® CAN WAIVE OR CHANGE.



# **IMPORTANT MESSAGE**

**WARNING - PLEASE READ**

**ADULT ASSEMBLY REQUIRED**

**CHOKING HAZARD - Small Parts**

**NOT** for children under 3 years of age.

## **WARNING:**

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risks of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

# WARNINGS

## Please read these warnings and the information in this manual in its entirety.

Failure to comply with the following instructions may increase the risk of serious injury and/or death:

- This unit must be assembled and disassembled by **ADULTS ONLY**.
- Children must be supervised at all times when using this equipment. **DO NOT** leave children unattended at any time.
- Children **MUST NEVER** use the trampoline unless supervised by a responsible adult with knowledge of trampoline use.
- This trampoline is **SUITABLE** for use by most children **3 TO 7 YEARS OF AGE**.
- **DO NOT** exceed the **MAXIMUM WEIGHT** limit of **75lbs (35kgs)** regardless of age.
- This trampoline is **NOT** for adult use.
- This trampoline is only designed for normal residential indoor use. It is **NOT** intended for commercial applications and/or in public areas such as schools, parks, nurseries, day schools, day cares, etc.
- For **INDOOR USE ONLY**: Your trampoline should be placed at a safe distance from any obstructions, stairways, windows, furniture, appliances, etc.
- **DO NOT** allow more than one person on the trampoline at a time.
- **DO NOT** wear glasses or helmets when using the trampoline.
- **DO NOT** fall or bounce on your knees — this can cause serious injury.
- **DO NOT** somersault - this can cause serious injury resulting in paralysis or death.
- **DO NOT** allow other persons to go under, sit, stand or lie on or near the frame pads or mat while the trampoline is in use.
- Mount and dismount the trampoline with care as injury may result.
- **DO NOT** use or allow use of the trampoline under the influence of any substance or medication which may impair the supervisor's or jumper's judgment and/or coordination.
- **ALWAYS** remove jewelry, belt buckles, or any other sharp objects before using the trampoline.
- **ALWAYS** jump in the middle of the trampoline bed.
- **ALWAYS** secure the trampoline against unauthorized and unsupervised use.
- **ALWAYS** wear socks when using the trampoline.
- **NEVER** wear footwear (e.g. shoes) when using the trampoline.
- Before using this product, inspect and replace any worn, defective or missing parts. Although the cord, pad, foam and mat are made to take a lot of wear, over time these parts may need to be replaced. It is important to check the trampoline periodically to ensure the frame is steady and all parts are in good condition.
- If any part of the trampoline requires cleaning, simply wipe with a damp cloth. (Do not jump on the trampoline after cleaning until completely dry)
- If the paint is chipped, we recommend you lightly rub the damaged area and cover using a non-toxic enamel paint.
- **IMPORTANT**: While no regular maintenance is required, you must inspect the trampoline before each use and replace any worn, defective, or missing parts. **ALWAYS** supervise your children while they are playing on or around the trampoline.
- The unit is **NEVER** to be used by more than one child at a time.
- The trampoline is designed so the child can bounce and balance on the mat. Successfully meeting this challenge builds children's confidence as well as helping muscular development and coordination. Confidence depends on success - so it is important to allow your children to learn at their own pace, giving them a helping hand when necessary.
- **NEVER** allow your child to attempt somersaults or flips on this trampoline as it is not designed for such play features.
- The trampoline should **NOT** be used in conjunction with, or attached to any other play equipment.
- The trampoline handle is only intended to assist your child with controlling their bounce and maintaining their balance on the mat. **NEVER** use the handle for any other purpose or as climbing feature.
- This trampoline is **NOT** intended to be used by adults.
- Children are **NOT** to stand or sit on the edge of the trampoline.
- Children are **NOT** to perform knee or drop bounces on the trampoline.
- The following conditions could represent potential hazards: Missing, improperly positioned, or insecurely attached frame padding; punctures, frays, tears, or holes worn in the bed or frame padding; deterioration in the stitching or fabric of the bed or frame padding; frayed or damaged bungee cord; a bent or broken frame; a sagging jump mat, or sharp protrusions on the frame or suspension system. Cease using trampoline immediately and secure it against unauthorized use if any of these conditions are present.

# ASSEMBLY WARNINGS

---

- Please read and refer to other warnings and use information in the trampoline instructions before use.
- Please read and refer to other warnings and use information in the Safe Play Tips before use.
- The trampoline handle is only intended to assist your child with controlling their bounce and maintaining their balance on the mat. The handle should NOT be used for any other purpose or as climbing feature.
- Dispose of all packaging materials safely and per local ordinance.
- Ensure you have all of the parts listed in the Parts List. If any are missing please contact customer service.
- Take a few minutes to familiarize yourself with the contents and instructions before attempting assembly.
- When you are ready to start, make sure that you have adequate space for assembly.
- ADULT ASSEMBLY REQUIRED
- TWO ADULTS ARE REQUIRED TO ASSEMBLE



# PARTS LIST

---

Part #	Description	QTY	Part#	Description	QTY
1	Top Rail Frame	x3	6	Trampoline Pad	x1
2	Legs	x6	7	Trampoline Mat	x1
3	Left Handle Base	x1	8	Bungee Cord Ball	x1
4	Right Handle Base	x1	9	Bungee Cord	x1
5	Center Handle Bar	x1	-	-	-

# ASSEMBLY INSTRUCTIONS

---


A



## STEP 1:

- A. Connect 3X (Part 1) Top Rail Frame pieces to make the trampoline frame. Make sure that the metal push tabs are secure in each connection on the frame before proceeding.
- B. To connect the third and final section of the top rail frame, push down on the last joint until the metal tab is fully inserted and snaps into place.

B





# ASSEMBLY INSTRUCTIONS

---



## STEP 2:

Thread at the end of the bungee cord through the pre-made loop.



## STEP 3:

A. Center the trampolene mat within the completed frame (diagram 3).

## NOTE:

To assist in centering the trampolene mat, there are four sip ties included. To use, thread 1 zip tie at each "Compass point" (N, S, E, W) through the fabric loops. Make sure when attaching these ties that you do not pull them too tight, so that the Matt stays centered within the frame.

B. Begin to thread the bungee cord through the pre-sewn fabric loops, wrapping the cord once around the trampolene frame after each fabric loop.

C. Do not pull the cord to tightly when beginning this process, as you want to keep the mat as centered as possible will threading the bungee cord. The court should be snug, but not pulled taut around the trampolene frame.



# ASSEMBLY INSTRUCTIONS

---



## STEP 4:

- A. Continue to thread the Bungee Cord through the fabric loops, wrapping it once around the Top Rail Frame sections after each fabric loop as you work your way around the trampoline frame.
- B. Keep the Trampoline Mat centered within the frame. Periodically check to make sure that it is not pulling too much to one side (especially where you first started threading the cord.)
- C. Leave a small amount of slack, and do not pull the cord too tightly as you progress to the Bungee Cord's end.
- D. As shown in the picture, you will reach the end of the cord with 3 or 4 fabric loops remaining. This is normal, as significant tension must be applied to the cord to achieve the proper bounce when complete.

## NOTE:

It is strongly recommended that you enlist the help of another adult before proceeding to the next two steps, as you will need to apply significant force to the bungee cord in order to join the two ends.

# ASSEMBLY INSTRUCTIONS

---



## STEP 4:

### NOTE:





Be careful of pinch points at the areas where the cord contacts the frame when performing this step.

- A. In order to join the two ends of the Bungee Cord while keeping the mat centered, you should create the necessary slack in the cord by pulling it as taut as possible from the last 4 or 5 wraps you made around the trampoline frame first, and then from the pre-made loop end of the cord last.
- B. If you notice that the Trampoline Mat is touching the frame on one side or another, and there is no slack in those corresponding cord wraps around the trampoline frame, you should carefully work some cord slack in that direction until you are able to re-center the Trampoline Mat.
- C. When you are complete, it should look like the picture above.



# ASSEMBLY INSTRUCTIONS

---



## STEP 6:

- A. Slide the Bungee Cord Ball into the Bungee Cord (Diagram 1).
- B. Pull on the cord and hold the tension so that you can tie off a knot on the end to prevent the ball from slipping, as shown in Diagram 2. Make sure the knot is secure.
- C. Creating slack on the pre-made loop end of the cord, open the loop enough to fit the ball through the loop.
- D. Make sure the loop is snug against the ball, so it will not slip during use. There should be significant tension on the cord to achieve the proper bounce. If the cord is too loose, you should tie off a second knot below the first on the ball end of the cord for proper tension.



# ASSEMBLY INSTRUCTIONS

---

A



## STEP 7:



A. Your completed mat, cord and frame assembly should look like the picture below.

B. As shown in the pictures below, attach the Trampoline Pad by fitting the precut holes in the pad over the Leg Housings.

B



# ASSEMBLY INSTRUCTIONS




## STEP 8:

- A. Following the pattern shown in Diagram 2, insert 4x Legs into the Leg Housings, making sure the metal push buttons snap securely into the holes into each Leg Housing.
- B. As shown in diagram 3, take the remaining 2x Legs, and place 1x Handle Base over each Leg.
- C. Take the Leg/Handle Base assembly, and place it onto the Leg Housing.
- D. First, secure the Leg's push button into the Leg Housing, then secure the push button through the hole in the Handle Base. You may have to rotate the Handle Base slightly to fit the push button through its hole.

## Note:


Make sure the Handle Base "ends" are pointing directly towards each other (see picture on next page) before proceeding. If they are not, switch the Legs that the Handle Bases are on.

# ASSEMBLY INSTRUCTIONS



## STEP 9:

- A. Attach the Center Handle bar to one Handle Base, securing it with the push button on the Handle base.
- B. Slide the other end of the Center Handle Bar onto the remaining Handle Base until it snaps securely into place. Peel the foam back slightly on the Center Handle Bar once it is in place to make sure the push buttons are correctly aligned through the holes.



# FREQUENTLY ASKED QUESTIONS

---

- Question: "The bungee cord has snapped/ become frayed, why did this happen?"

Answer: Make sure that the mat was installed properly and is centered within the frame an incorrectly installed Mat will put Excess tension on the certain areas of the bungee cord. Also make sure that you are following the 75lb. Weight limit on this trampoline, specifically making sure that only one child is on the trampoline at a time.

If you are still within your warranty period (90 Days from Initial Purchase) You should contact customer service.

- Question: "The foam padding or mat is damaged, what should I do?"

Answer: If you are still within your warranty period (90-Days from Initial purchase) You should contact customer service.

You can also purchase select replacement mini-trampoline parts at: [www.PureFun.Net](http://www.PureFun.Net)