

Start-Up and Shut Down Procedures – Demolition Hydraulic Excavators

SAFETY.CAT.COM™

	ate_	lime		
Serial Number	Machine Hours			
What are you inspecting?	✓	What are you looking for?	✓	Evaluator Comments
For more information, please refer to the Operation and Maintenance	Manua	al or any other applicable manuals and	d in	structions for this product. If you
have questions, please contact your local Caterpillar dealer.				
STARTING THE MACHINE				
Perform walk around inspection				
Mount the machine using 3 points of contact				
Turn the battery disconnect switch to ON				
Disengage the hydraulic lockout control				
Adjust seat, fasten seat belt				
Make sure all implements are grounded				
Move the joysticks to HOLD position				
Make sure all personnel are clear of machine				
Set the throttle control to LOW IDLE				
Turn the key start switch to ON				
Perform pre-start checks on the monitor				
Turn the key start switch to START and crank engine				
MACHINE WARM-UP				
Check gauges and warning lights to ensure readings are in				
normal operating range				
Allow machine to warm up for 5 minutes at low idle				
Engage hydraulic lockout control				
Engage and disengage implement controls to help speed				
warm-up of hydraulic components				
Cycle all controls to allow warm oil to circulate through all				
cylinders and lines. Verify all controls are functioning				
properly Continue to monitor gauges and warning lights				
Continue to monitor gauges and warming lights				
MOVING THE MACHINE				
Make sure area is clear				
Sound horn to warn others				
Raise lowered implements				
Make sure position of upper structure and undercarriage is				
known before moving machine				
Turn engine speed dial to increase RPM to desired speed	_			
Push travel levers or pedals forward to travel forward				
MACHINE SHUT DOWN				
Park machine on smooth, level area				
Lower all hydraulic implements	_			
Set the hydraulic lockout control				
Move throttle control to LOW IDLE and run 5 minutes				
Turn key start switch to OFF and remove key				
Turn battery disconnect switch to OFF				
Dismount machine using 3-point contact				
Conduct post-operation walk around inspection				

HTTP://SAFETY.CAT.COM V0810.1

