

QwikCheck[®]

Qwik**Check**® Acid Test Kit

Qwik**Check**® is ideal for preventive maintenance checks and for verifying proper acid clean up. The Qwik**Check**® indicator paper is golden yellow before testing and will turn pink or red upon being exposed to as little as 1 part per million (PPM) of acid.

Perform a Qwik acid test on operating systems. Ideal for preventative maintenance checks or for verifying proper acid clean-up after a compressor burn-out / change-out.

- 2-Second Refrigeration Acid Test
- Tests to ARI-700 limit of 1 PPM
- Tests for Inorganic Acid (including POE)
- Meets EPA Venting Rules





Directions:

- 1. Insert the valve core depressor into the center of the suction side of the vapor service valve while the system is operating.
- 2. Allow vapor to flow through the <code>QwikCheck®</code> for 3-seconds. If the indicator paper does not change color, hold for another 3-seconds. If the indicator paper still does not change color, inorganic acid was not detected.
- **3.** If the indicator paper changes color slightly, add Qwik**Shot**® to remove the acid. If the paper turns red, the acid level is very high. Change the oil and the filter-drier, and then add Qwik**Shot**®.

For more details or information about QwikCheck® visit www.qwik.com

Qwik**Check**® 5-Second Acid Test Kit - Part # QT2000 U.S. Patents #6,514,765 & #5,770,048

QwikProducts™ is a trademark of Mainstream Engineering Corporation. QwikCheck® and QwikShot® are registered trademarks of Mainstream Engineering Corporation, Rockledge, Florida 32955, (321) 631-3550 All QwikProducts™ are made in the USA



