		2021 Cat Convenience - New Planned Maintenance Schedule - Track Loaders					
				See Contract for a	pplicable intervals.		
-	Sales Model	953K	953-12	963K	963K	963-12	973K
Interval	Serial Number	LJT	LTL	YDR	LBL	LTT	MKL
	Fluids SOS - Number of bottles and analysis	1	1	1	1	1	1
250 Hours	Engine Oil Filter	-	-	Х	x	-	-
	Fuel Filter In-Line	Х	-	-	X	-	-
	SOS Coolant Sample Level 2 bottle and analysis	Х	Х	Х	Х	Х	Х
	Fluids SOS - Number of bottles and analysis	4	4	4	4	4	4
500 Hours	Eng Oil Filter Element	Х	Х	Х	Х	Х	Х
000 110013	Fuel In-line	Х	Х		Х	Х	
	Fuel Water Seperator Primary	Х	Х	Х	Х	Х	х
	Fuel Secondary	Х	Х	Х	Х	Х	X (x2 qty.)
750 Hours	Fluids SOS - Number of bottles and analysis	1	1	1	1	1	1
	202 Coolant Sample Level 4 hottle and analysis	~	×	V	~	×	V
	SOS Coolant Sample Level 1 bottle and analysis Fluids SOS - Number of bottles and analysis	X 4	X 4	X 4	X 4	X 4	4 X
	Engine Air Primary Element	X	X	X	X	X	X
	Engine Air Secondary Element	x	x	X	x	X	x
	Eng Oil Filter Element	X	X	X	X	X	X
1,000 Hours	Fuel In-line	X	X		X	X	
	Fuel Water Seperator Primary	X	X	х	X	X	x
	Fuel Secondary	X	X	X	X	X	X (x2 qty.)
	Fuel Tank Cap	-	-	-	-	-	Х
	Transmission Filter Element	Х	X (x2 qty.)	Х	Х	X (x2 qty.)	Х
	Crankcase Breather Filter	Х	Х	-	Х	X	-
	Hydraulic Oil Filter	-	x	-	-	Х	-
	Cab Air Filter Recirculating	X	X	X	X	X	X
	Cab Air Filter Fresh	Х	Х	Х	Х	Х	Х
1,250 Hours	Fluids SOS - Number of bottles and analysis	1	1	1	1	1	1
	SOS Coolant Sample Level 1 bottle and analysis	X	X	X	X	X	Х
	Fluids SOS - Number of bottles and analysis	4	4	4	4	4	4
	Eng Oil Filter Element	X	X	X	X	X	X
1,500 Hours	Fuel In-line	X	X	-	X	X	-
	Fuel Water Seperator Primary	X	х	X	X	X	X
	Fuel Secondary	X	X	X	X	X	X (x2 qty.)
4 750 Hours	Fluide SOS Number of bottles and evolusie	1	1	4	1	4	
1,750 Hours	Fluids SOS - Number of bottles and analysis	1		1	1	1	1
	SOS Coolant Sample Level 2 bottle and analysis	Х	Х	Х	Х	Х	Х
2,000 Hours	Fluids SOS - Number of bottles and analysis	4	4	4	4	4	4
	Engine Air Primary Element	X	X	X	X	X	X
	Engine Air Secondary Element	X	X	X	X	X	X
	Eng Oil Filter Element Fuel In-line	X X	X X	X -	X X	X X	X
	Fuel Water Seperator Primary	x	x	X	x	x	x
	Fuel Secondary	X	X	X	X	X	X (x2 qty.)
	Fuel Tank Cap	-	-	-	-	-	x
	Fuel Tank Breather	-	X		-	X	-
	Crankcase Breather Filter	Х	Х	-	Х	Х	Х
	Hydraulic Oil Filter		Х			Х	
	Hydraulic Tank Breather AS	Х	Х	Х	Х	Х	Х
	Trasmission Filter Element	Х	X (x2 qty.)	Х	Х	X (x2 qty.)	Х
	Cab Air Filter Recirculating	X	X	X	X	X	X
	Cab Air Filter Fresh	Х	Х	X	Х	Х	Х
2,250 Hours	Fluids SOS - Number of bottles and analysis	1	1	1	1	1	1
	SOS Coolant Sample Level 1 bottle and analysis	X	X	X	Х	X	Х
	Fluids SOS - Number of bottles and analysis	4	4	4	4	4	4
	Eng Oil Filter Element	x	x	X	X	X	x
2,500 Hours	Fuel In-line	x	x	-	x	x	-
	Fuel Water Seperator Primary	х	х	Х	х	Х	х
	Fuel Secondary	Х	х	Х	Х	Х	X (x2 qty.)
2,750 Hours	Fluids SOS - Number of bottles and analysis	1	1	1	1	1	1
2,750 110013		•			-		
	SOS Coolant Sample Level 1 bottle and analysis	X	X	X	X	X	Х
	Fluids SOS - Number of bottles and analysis	4	4	4	4	4	4
	Engine Air Primary Element	X	X	X	X	X	x
	Engine Air Secondary Element	X	x	X	x	x	x
	Eng Oil Filter Element Fuel In-line	x x	X X	- X	× ×	× ×	X
	Fuel In-line Fuel Water Seperator Primary	X	X	- X	X	X	- X
3,000 Hours	Fuel Water Seperator Primary Fuel Secondary	x	x	X	x	X	X (x2 qty.)
	Fuel Tank Cap	-	-	-	-	-	X (x2 qty.)
	Transmission Filter Element	X	X (x2 qty.)	X	x	X (x2 qty.)	x
	Crankcase Breather Filter	x	X	-	x	X	-
	Hydraulic Oil Filter	-	x	-	-	x	-
	Cab Air Filter Recirculating	х	х	Х	х	Х	х
	Cab Air Filter Fresh	х	х	х	х	х	х
3,250 Hours	Fluids SOS - Number of bottles and analysis	1	1	1	1	1	1
0,200 110013							
	SOS Coolant Sample Level 1 bottle and analysis	X	X	X	X	X	X
	Fluids SOS - Number of bottles and analysis	4	4	4	4	4	4
3,500 Hours	Eng Oil Filter Element	X	x	X	X	X	X
	Fuel In-line	X X	X X	- X	× ×	× ×	- X
	Fuel Water Seperator Primary Fuel Secondary	x	x	X	x	X	X (x2 qty.)
		^	^	~			λ (λ2 qty).)
3,750 Hours	Fluids SOS - Number of bottles and analysis	1	1	1	1	1	1

	SOS Coolant Sample Level 2 bottle and analysis	X	X	X	X	x	X
	Fluids SOS - Number of bottles and analysis	4	4	4	4	4	4
	Engine Air Primary Element	X	X	X	X	X	X
	Engine Air Secondary Element	X	X	X	X	X	X
	Eng Oil Filter Element	X	X	Х	X	X	X
	Fuel In-line	X	X	-	Х	Х	-
4,000 Hours	Fuel Water Seperator Primary	X	X	X	Х	Х	X
	Fuel Secondary	X	Х	Х	Х	Х	X (x2 qty.)
	Fuel Tank Cap	-	-	-	-	-	X
	Fuel Tank Breather	-	X		-	Х	-
	Crankcase Breather Filter	X	Х	-	Х	Х	Х
	Hydraulic Oil Filter	-	X	-	-	Х	-
	Hydraulic Tank Breather AS	X	Х	Х	X	Х	Х
	Trasmission Filter Element	X	X (x2 qty.)	Х	X	X (x2 qty.)	Х
	Cab Air Filter Recirculating	Х	Х	Х	Х	Х	Х
	Cab Air Filter Fresh	X	Х	Х	Х	Х	Х
4,250 Hours	Fluids SOS - Number of bottles and analysis	1	1	1	1	1	1
	SOS Coolant Sample Level 1 bottle and analysis	X	X	Х	Х	х	X
4,500 Hours	Fluids SOS - Number of bottles and analysis	4	4	4	4	4	4
	Eng Oil Filter Element	X	X	X	x	x	X
	Fuel In-line	X	X	-	x	x	-
	Fuel Water Seperator Primary	X	X	х	x	x	X
	Fuel Secondary	Х	X	Х	Х	X	X (x2 qty.)
	,						
4,750 Hours		1					
-,/00 Hours	Fluids SOS - Number of bottles and analysis	1	1	1	1	1	1
-,,, ou nours	Fluids SOS - Number of bottles and analysis SOS Coolant Sample Level 1 bottle and analysis	1 X	1 X	1 X	1 X	1 X	1 X
-,, 100 Hours							
-,130 Hours	SOS Coolant Sample Level 1 bottle and analysis	X	X	X	X	X	Х
-,730 Hours	SOS Coolant Sample Level 1 bottle and analysis Fluids SOS - Number of bottles and analysis	X 4	X 4	X 4	X 4	X 4	X 4
-, rou nours	SOS Coolant Sample Level 1 bottle and analysis Fluids SOS - Number of bottles and analysis Engine Air Primary Element	X 4 X	X 4 X	X 4 X	X 4 X	X 4 X	X 4 X
, roo nouts	SOS Coolant Sample Level 1 bottle and analysis Fluids SOS - Number of bottles and analysis Engine Air Primary Element Engine Air Secondary Element	X 4 X X X	X 4 X X	X 4 X X	X 4 X X X	X 4 X X X	x 4 x x x
	SOS Coolant Sample Level 1 bottle and analysis Fluids SOS - Number of bottles and analysis Engine Air Primary Element Engine Air Secondary Element Eng Oil Filter Element	X 4 X X X X	X 4 X X X X	X 4 X X X X	X 4 X X X X	X 4 X X X X	X 4 X X X X
4,750 Hours	SOS Coolant Sample Level 1 bottle and analysis Fluids SOS - Number of bottles and analysis Engine Air Primary Element Engine Air Secondary Element Eng Oil Filter Element Fuel In-line	X 4 X X X X X	X 4 X X X X X	X 4 X X X -	X 4 X X X X X	X 4 X X X X	X 4 X X X -
	SOS Coolant Sample Level 1 bottle and analysis Fluids SOS - Number of bottles and analysis Engine Air Primary Element Engine Air Secondary Element Eng Oil Filter Element Fuel In-line Fuel Nature Seperator Primary	X 4 X X X X X X X	X 4 X X X X X X X	X 4 X X X - X	X 4 X X X X X	X 4 X X X X X X	X 4 X X X - X
	SOS Coolant Sample Level 1 bottle and analysis Fluids SOS - Number of bottles and analysis Engine Air Primary Element Engine Air Secondary Element Eng Oil Filter Element Fuel In-line Fuel Water Seperator Primary Fuel Secondary	X 4 X X X X X X X X	X 4 X X X X X X X X X	X 4 X X X - X X X	X 4 X X X X X X X X X	X 4 X X X X X X X X	X 4 X X - X X (x2 qty.)
	SOS Coolant Sample Level 1 bottle and analysis Fluids SOS - Number of bottles and analysis Engine Air Primary Element Engine Air Secondary Element Eng Oli Filter Element Fuel In-line Fuel Water Seperator Primary Fuel Secondary Fuel Secondary Fuel Tank Cap	X 4 X X X X X X X X X	X 4 X X X X X X X X	X 4 X X - - X X - - -	X 4 X X X X X X X -	X 4 X X X X X X X -	X 4 X X - X X X X X X X X X
	SOS Coolant Sample Level 1 bottle and analysis Fluids SOS - Number of bottles and analysis Engine Air Primary Element Engine Air Secondary Element Eng Oil Filter Element Fuel In-line Fuel Water Seperator Primary Fuel Secondary Fuel Tank Cap Transmission Filter Element	X 4 X X X X X X X X X X X	X 4 X X X X X X X X X X X X X X X X X X	X 4 X X - X X X X X X	X 4 X X X X X X X X X X X	X 4 X X X X X X X X X X X X X X X X X X	X 4 X X - X X X X X X X X X X
	SOS Coolant Sample Level 1 bottle and analysis Fluids SOS - Number of bottles and analysis Engine Air Primary Element Engine Air Secondary Element Fuel Oline Fuel Inline Fuel Vater Seperator Primary Fuel Secondary Fuel Secondary Fuel Tank Cap Transmission Filter Element Crankcase Breather Filter	X 4 X X X X X X X X X X X X	X 4 X X X X X X X X X X X X X X X X X X	X 4 X X - X X - X - X - X - X -	X 4 X X X X X X - X X X X	X 4 X X X X X X X X X X X X X X X X X X	X 4 X X - X X X (x2 qty.) X X -

EXCLUSIONS

Ensure that all safety information, warnings, and instructions are read and understood before any operation or any maintenance procedures are performed. The user is responsible for the performance of maintenance, including all adjustments, the use of proper lubricants, fluids, filters, and the replacement of components due to normal wear and aging. Failure to adhere to proper maintenance intervals and procedures may result in diminished performance of the product and/or accelerated wear of components. Use mileage, fuel consumption, service hours, or calendar time, WHICH EVER OCCURS FIRST, to determine the maintenance intervals. Models in the above table with 1,000 hour oil drain intervals assumes the machine is operated in a Standard Service Application, utilizes Cat Recommended Fluids and maintains timely SOS sampling. Consult model and serial number specific OMM for alternate drain and maintenance options. The maintenance activities in the table above reflect commonly required activities. Machines may require more frequent maintenance and/or additional parts, depending on factors such as severe applications or extreme operating and evironmental conditions. This chart is not intended to be a comprehensive list of all maintenance activities that may be recommended or required and may not contain fluids, maintenance schedules or additional requirements associated with the above maintenance activities. Refer to your CVA contract for specific terms associated with the agreement. Some recommended maintenance activities excluded from CVA contracts are listed below

- Valve gaskets excluded for valve lash checks.
- ** Coolant is recommended to be replaced every 2 years, unless Used - Convenienceed by utilizing Used - Convenienceed Life Coolant (ELC) additive.
- *** The maintenance manual recommends cleaning or replacing the DPF with a new or remanufactured DPF every 5000 hours
- **** Seat Belts are recommended to be replaced every 3 years.
- ***** A/C Dryers are recommended to be replaced every 2000 hour interval.
- ***** Radiator caps are recommended to be replaced every 3000 hour interval.
- Thermostats are reccomended every 2000 hours
- .
- Fluids data for informational purposes only and are not provided in parts-only CVA's unless expressly stated in your contract.

This marketing tool does not represent a contract or obligation of any kind between Caterpillar Financial Aftermarket Solutions Corporation or its affiliates, and the equipment owner. For details on any Cat® Customer Value Agreement (CVA), including a complete description of the terms, conditions, and/or exclusions, contact a participating Cat dealer.

All graphics and lists in this marketing tool are provided solely for general information purposes and are not intended to be a solicitation or an offer to purchase any product or service.

To the extent that the above publication(s), bulletin(s), and/or any designated contract(s) are ambiguous or inconsistent with the CVA contract language, the terms of the CVA contract shall govern.

© 2021 Caterpillar. All Rights Reserved. CAT, CATERPILLAR, LET'S DO THE WORK, their respective logos, "Caterpillar Corporate Yellow," the "Power Edge" and Cat "Modern Hex" trade dress as well as corporate and product identity used herein, are trademarks of Caterpillar and may not be used without permission.