

# Kwikset

## INTERCONNECT WITH KEY CONTROL DEADBOLT



### A SMART SOLUTION FOR MULTIFAMILY HOUSING

- Meets fire code rating for emergency panic exit
- ANSI/BHMA Graded
- Meets 3 hour UL rating
- Lever options are in compliance with the American National Standards Institute (ANSI A117.1) and the Americans with Disabilities Act (ADA).
- Fits standard door prep - 5 1/2" center to center
- Easy installation
- Features SmartKey Security™ - Re-Key in Seconds

THE #1 SELLING U.S. LOCK BRAND\*

\*Source: TraQline US quarterly brand unit share report, Q4 2006 through Q3 2017

81896-12/17

# Kwikset


## INTERCONNECT SPECIFICATIONS

<b>Door Prep</b>	Crossbore 2-1/8", Edge Bore 1", 5-1/2" center-to-center only.
<b>Backset</b>	Complete locksets: 2-3/4" UL or 2-3/8" UL.
<b>Door Thickness</b>	1-3/4" and 2-1/4".
<b>Cylinder</b>	508 SMT - utilize 816 deadbolt with SmartKey Security™.
<b>Faceplates</b>	Complete locksets: No default - must specify faceplate. 1" round corner, 1" square corner, 1-1/8 WFL square. Complete locksets: UL 3028, 3031 (WFL option 3846).
<b>Strikes</b>	Deadbolt Strike: UL 5278, 3223 (WFL 4632 opt.).
<b>Door Handing</b>	506, 508, 505, 507 - reversible 502, 502 - specify handing.
<b>ANSI/BHMA</b>	508
<b>ADA</b>	Lever options are in compliance with the American National Standards Institute (ANSI A117.1) and the Americans with Disabilities Act (ADA).
<b>UL</b>	Meets 3 hour fire rating for all functions.

## KEY CONTROL DEADBOLT SPECIFICATIONS


<b>Standard Door Prep</b>	Crossbore 2-1/8", Edge Bore 1", Latch Face 1" x 2-1/4".
<b>Door Thickness</b>	1-3/4" or 1-3/8" (with adaptor kit).
<b>Cylinder</b>	2 SmartKey Security™ cylinders: 1 standard Kwikset for users, 1 unique patented keyway for 1-Key Control.
<b>Faceplate</b>	1" x 2-1/4".
<b>Strike</b>	1-1/4" x 3-5/8".
<b>Bolt</b>	1" throw.
<b>ANSI/BHMA</b>	Grade 2 Certified.
<b>ADA</b>	Interior tn piece meets 4.13.9 ADA.
<b>UL</b>	Meets 3 hour fire rating for 817 UL Optional 1/3 hour UL fire rating for all functions.

## INTERCONNECT DIMENSIONS



Design	A	B	C	D	E	F
Interconnect	1 7/16"	2 15/32"	5 1/2"	2 53/64"	10"	2 31/32"

## DEADBOLT DIMENSIONS




## FINISHES




## HOW TO RE-KEY YOUR LOCK IN SECONDS



Make sure you have your current key and SmartKey tool



1 Insert the key that currently operates your lock, and rotate it 90° clockwise.



2 (A) Insert the SmartKey tool fully and firmly into the SmartKey hole. (B) Remove the SmartKey tool and the current key.



3 (A) Fully insert your new key into the lock, and rotate it 180°. (B) Rotate the new key 90° back to the starting position, and remove it. Your lock is now re-keyed to your new key, and your old key will no longer operate the lock.