
Portable System Owners Manual

1-800-Spalding



Adult Assembly Required.

This manual, accompanied by sales receipt, should be saved and kept on hand as a convenient reference, as it contains important information about your model.





READ AND UNDERSTAND OPERATOR'S MANUAL BEFORE USING THIS UNIT.

FAILURE TO FOLLOW OPERATING INSTRUCTIONS COULD RESULT IN INJURY OR DAMAGE TO PROPERTY.

Write Model Number From Box Here:

REQUIRED TOOLS AND MATERIALS: • (2 each) Wrenches Garden Hose or Sand • 2 Capable Adults · Tape Measure 1/2" 9/16" AND/OR Wood Board (scrap) (2) Socket Wrenches and Sockets Sawhorse or Support Table 9/16" · Hammer or Mallet Optional: Large & Small Extension Adjustable Wrenches • Step Ladder 8 ft. (2.4m) • Phillips-Head Screwdriver · Safety Glasses

Toll-Free Customer Service Number for U.S: **1-800-558-5234**, For Canada: **1-800-284-8339**, For Europe: **00 800 555 85234** (Sweden: **009 555 85234**), For Australia: **1300 367 582**


Internet Address: www.spalding.com www.spalding.com.au


BEFORE YOU START


To ensure optimal playability of backboard system, a close tolerance fit between the elevator components and hardware is required. Test-fit large bolts into large holes of elevator tubes, backboard brackets, and triangle plates. Carefully rock them in a circular motion to ream out any excess paint from holes if necessary.

NOTE: Not all items pictured are included with every model.















568090

11/06



NOTICE TO ASSEMBLERS

Adult Assembly Required. Dispose of ALL packaging materials promptly. As with all products, periodically inspect for loose small parts.

Assembled unit MUST be filled with sand or water at ALL times.

ALL basketball systems, including those used for DISPLAYS, MUST be assembled and installed according to instructions. Failure to follow instructions could result in SERIOUS INJURY. It is NOT acceptable to devise a makeshift support system.



SAFETY INSTRUCTIONS



FAILURE TO FOLLOW THESE SAFETY INSTRUCTIONS MAY RESULT IN SERIOUS INJURY OR PROPERTY DAMAGE AND WILL VOID WARRANTY.


Owner must ensure that all players know and follow these rules for safe operation of the system.

To ensure safety, do not attempt to assemble this system without following the instructions carefully. Check entire box and inside all packing material for parts and/or additional instruction material. Before beginning assembly, read the instructions and identify parts using the hardware identifier and parts list in this document. Proper and complete assembly, use, and supervision are essential for proper operation and to reduce the risk of accident or injury. A high probability of serious injury exists if this system is not installed, maintained, and operated properly.

- If using a ladder during assembly, use extreme caution.
- Check base regularly for leakage. Slow leaks could cause the system to tip over unexpectedly
- Seat the pole sections properly (if applicable). Failure to do so could allow the pole sections to separate during play and/or during transport of the system.
- Climate, corrosion or misuse could result in system failure.
- If technical assistance is required, contact Customer Service.
- Minimum operational height is 6' 6" (1.98m) to the bottom of backboard.

Most injuries are caused by misuse and/or not following instructions.

Use caution when using this unit.



IMPORTANT!

Remove all contents from boxes.

Be sure to check inside pole sections,
hardware and additional parts are packed inside.






Λ

WARNING!



IF YOUR SYSTEM IS EQUIPPED WITH AN ACRYLIC OR GLASS BACKBOARD, EXAMINE BACKBOARD FOR ANY DAMAGE THAT MAY HAVE OCCURRED DURING SHIPMENT. CRACKS IN THE BACKBOARD COULD RESULT IN SUDDEN BREAKAGE. IF BACKBOARD IS DAMAGED IN ANY WAY PRIOR TO OR AFTER ASSEMBLY, CALL TOLL-FREE NUMBER: U.S. 1-800-558-5234; CANADA: 1-800-284-8339; www.spalding.com



PARTS LIST - See Hardware Identifier ✓ <u>Item</u> <u>Qty</u>. <u>Part No</u>. <u>Description</u> ✓ Item Qty. Part No. **Description** □ 26 Bolt, Hex Flange, 5/16-18 x 2 Long Base Strut, Pole to Base Pole Pad 80034403 Screw Jack Assembly Cover Plate, Rim Bolt, Hex Head, 1/2-13 x 7 Long FR908559 Top Pole Section FR908558 Middle Pole Section Spacer, Plastic, 0.530 I.D. x 0.25 Long П FR918403 Bottom Pole Section Lock Nut, Hex 1/2-13 Wheel Bracket Elevator Tube, Lower - Long Wheel. 3.5" Label, Height Adjustment and Moving FR568090 Label, Height Adjustment and Moving, French Rod. Axle Nut, Ny-lock, 5/16-18 Elevator Tube, Upper - Short Cap, Cover, Height Indicator Spacer, 0.530 I.D. x 1" Long Bolt, Hex Head, 5/16-18 x 4.5 Long Washer, Flat, 0.625 I.D. x 1.5 O.D. Pushnut, 7/16 Shaft Diameter Cap, Pole Top 8* Hex Flange Nut 5/16-18 Screw, 1/4 x .375 Long Bracket, Pole Mount Frame, Base Carriage Bolt, 5/16-18 x 4.5 Long

□ 41

☐ 42

□ 43

□ 44

□ 46

□ 47

Cap, Base

Spring, Rim

Reinforcement Bracket

Bolt, Tee, 3/8-16, 3.25" Long

Bracket, Reinforcement, Slam Jam

Nut, Special, 3/8-16

Bracket, Slam Jam



Bolt, Hex Head, 5/16-18 x .75 Long

Bolt, Hex Head, 5/16-18 x 2.75 Long

Plate, Pole Mounting

Handle, Elevator Assembly

Bolt, Hex Head, 1/2-13 x 2 Long

Bolt, Hex Head, 3/8-16 x 2 Long

Pin, Actuator Assembly

Washer, Flat, 5/16

□ 17

□ 19

 \square 20

 \square 22


□ 24

Net


NOTE


Hardware kit is designed for more than one style of basketball system. Not all hardware will be used.


^{*} YOU MAY HAVE EXTRA PARTS WITH THIS MODEL.




HARDWARE IDENTIFIER (PLASTIC SPACERS CAPS AND CLIPS)









HARDWARE IDENTIFIER (OTHER)










This is what your system will look like when you've finished this section.




TOOLS REQUIRED FOR THIS SECTION

(2) Wrenches

AND/OR

(2) Socket Wrenches and Sockets




1/2" 9/16" Extension


Sawhorse or Support Table




Hammer or Mallet




Complete wheel assembly as shown in Figure A. Secure wheel bracket (7) and wheel assembly (Fig. A.) to the tank (1) with a bolts (18) and washers (24).




Correctly identify each pole section. Measure and mark a line, with tape or marker 4.5" (11.4 cm) from the top ends of the both the middle pole (5) and bottom pole (6).



Bounce middle pole section (5) into top section (4) using a wood scrap as shown until the top pole longer moves to the 4.5" (11.4 cm) line you made previously on the middle pole (5).





4.5" (11.4 CM)

6


Wood Scrap (not supplied)

Attach pole assembly to base (1) as shown. Secure pole assembly to base using bolts (25) and pole mounting plate (19) as shown.




WARNING!


TWO CAPABLE ADULTS REQUIRED FOR THIS PROCEDURE. FAILURE TO FOLLOW THIS WARNING COULD **RESULT IN SERIOUS INJURY** AND/OR PROPERTY DAMAGE.






0









7. Tip base assembly forward and slide base frame (40) underneath the base.







ASSEMBLY IS COMPLETED.




NUT'S OUTER EDGE.








Insert T-bolt (45) into Slam Jam bracket (44) then, attach that assembly to board using bolts (26) and nuts (14).





3.


Install Slam Jam Rim to Backboard

- **A.** Fit rim (34) securely into bracket (44) as shown. Allow T-bolt (45) to slip through center hole in rim (34).
- B. Install reinforcement bracket (46) onto T-bolt (45) as shown.
- C. Install spring (47) onto T-bolt (45) as shown.
- **D.** Install special nut (43) and washer (37) onto T-bolt (45).
- E. Tighten nut (43) until flush with end of T-bolt (45).












Roll completed assembly to desired position. Fill base with water (approx. 40 gallons (128 Liters)) or sand (approx. 475 lbs. (216 kg)) and rotate the cap (41) into base (1).



WARNING!





REQUIRED FOR THIS
PROCEDURE. FAILURE TO
FOLLOW THIS WARNING
COULD RESULT IN SERIOUS
INJURY AND/OR PROPERTY
DAMAGE.



DO NOT LEAVE ASSEMBLY UNATTENDED WHEN EMPTY; IT MAY TIP OVER.

CAUTION!






ADD TWO GALLONS (7.6 LITERS) OF NON-TOXIC ANTIFREEZE IN SUB-FREEZING CLIMATES.




<u>IF USING SAND</u>: 2 GALLONS OF ANTI-FREEZE IS <u>NOT</u> REQUIRED.


WARNING!




CAP (41) MUST BE TIGHTENED COMPLETELY AND SECURELY TO PREVENT LEAKAGE. CHECK WATER LEVEL BEFORE EACH USE! FAILURE TO FOLLOW THIS WARNING COULD RESULT IN SERIOUS INJURY AND/OR PROPERTY DAMAGE.




8. Install net (17).






SECTION C: BOARD PAD

TOOLS REQUIRED FOR THIS SECTION



Or





Portable Drill with Torque Adjustment

Socket Wrenches and Sockets




Phillips Screwdriver


PARTS LIST - See Hardware Identifier

\checkmark	<u>Item</u>	<u>Qty</u> .	<u>Part No</u> .	<u>Description</u>
	1	1	20157801	Board Pad, Left Section
	2	1	20157901	Board Pad, Right Section
	3	1	201580	Board Pad, Center Section
	4	6	201596	Screw, 1/4 x 1.25
	5	6	206303	Washer, Flat
	6	1	205355	Drill Bit, 11/64"

HARDWARE IDENTIFIER




#1 (1)



#2 (1)



#3 (1)



 \bigcirc

#5 (6)




#6 (1)




1


Using the holes which line up for your board size, attach center pad section (3) to left and right sections (1 and 2) and board using screws (4) and washers (5) as shown.

It may be necessary to use an 11/64 drill bit (6) to pre-drill on some backboards (Figure A). A center punch is recommended to mark hole locations prior to drilling to keep drill bit from wandering.



Attach left and right pad sections (1 and 2) to board using screws (4) and washers (5) as shown.





APPLY HEIGHT INDICATOR DECALS FIXEZ LES ETIQUETTES AUTOCOLLANTES DU REPERE DE HAUTEUR HÖHENANZEIGER-AUFKLEBER ANBRINGEN APLIQUE LAS CALCOMANÍAS DEL INDICADOR DE ALTURA



Apply Height Indicator Labels) to screw jack using a tape measure. Tools needed for this operation - Tape measure, Step Ladder 8 ft..

Appliquer les Etiquettes d'Indicateur de Hauteur visser la prise qui utilise un mètre. Les outils ont eu besoin de pour cette opération - le mètre, Echelle d'Etape 8 pied.

Verwenden Sie Höhenanzeigeretikette, Wagenheber zu schrauben, der ein Messband benutzt. Werkzeuge haben für diesen Betrieb - Messband, Schritt Leiter 8 Füße gebraucht.

Aplique Altura Etiquetas de Indicador enroscar gato que utiliza una medida de cinta. Las herramientas necesitaron para esta operación - la medida de Cinta, la Escalera 8 Pies.



Step 1 - Set unit to 7-1/2 feet (2.3 m) by adjusting the screw jack and measuring from the top of the rim to the playing surface. Place 7-1/2' (2.3 m) sticker in the middle of the hole of the screw jack cover as shown.

Marcher 1 - L'unité fixe à 7-1/2 pieds (2,3 m) en ajustant la prise de vis et mesurant du sommet du bord à la surface jouant. Placer 7-1/2' (2,3 m) l'autocollant au milieu du trou de la couverture de prise de vis comme indiqué.

Schreiten Sie 1 - Feste Einheit zu 7-1/2 Füßen (2,3 m) durch Einstellen des Schraubenwagenhebers und messend vom Oberteil des Rands zum spielenden auftaucht. Stellen Sie 7-1/2' (2,3 m) Aufkleber in der Mitte des Lochs der Schraubenwagenhebersdecke wie gezeigt.

El paso 1 - La unidad fija a pies 7-1/2 (2,3 M) ajustando el gato de tornillo y midiendo de la cima del borde a la superficie que juega. Coloque 7-1/2' (2,3 M) pegatina en medio del hoyo de la cobertura de gato de tornillo como mostrado.



Step two - Using a tape measure, set unit to 7 1/2 feet (2,3m) by adjusting the screw-jack and measuring from the top of the rim to the playing surface. Place the 7-1/2 foot (2,3m) sticker in the middle of the hole of the screw-jack cover as shown.

Marcher deux - Utiliser un mètre, une unité fixe à 7 1/2 pieds (2,3m) en ajustant la vis-prise et mesurant du sommet du bord à la surface jouant. Placer le 7-1/2 pied (2,3m) l'autocollant au milieu du trou de la couverture de vis-prise comme indiqué.

Schreiten Sie zwei - Benutzen eines Messbands, fester Einheit zu 7 1/2 Füße (2,3m) durch Einstellen des Schraube-wagenheber und messend vom Oberteil des Rands zum spielenden auftaucht. Stellen Sie den 7-1/2 Fuß (2,3m) Aufkleber in der Mitte des Lochs der Schraube-wagenheberdecke wie gezeigt.

El paso dos - Utilizando una medida de cinta, unidad fija a 7 1/2 pies (2,3m) ajustando el tornillo-gato y midiendo de la cima del borde a la superficie que juega. Coloque el pie 7-1/2 (2,3m) pegatina en medio del hoyo de la cobertura de tornillo-gato como mostrado.



Step three - Repeat step two for each subsequent height until the last sticker is in place at the 10 foot (3,04m) height.

Marcher trois - Répéter l'étape deux pour chaque hauteur subséquente jusqu'à ce que le dernier autocollant est à sa place au 10 pied (3,04m) la hauteur.

Schreiten Sie drei - Wiederholung schreitet zwei für jede folgende Höhe, bis der letzte Aufkleber an der richtigen Stelle am 10 Fuß (3,04m) Höhe ist.

El paso tres - Repite paso dos para cada altura subsiguiente hasta que la última pegatina esté en el lugar en el 10 pie (3,04m) altura.



TWO CAPABLE ADULTS REQUIRED FOR THIS PROCEDURE. FAILURE TO FOLLOW THIS WARNING COULD RESULT IN SERIOUS INJURY AND/OR PROPERTY DAMAGE.

DEUX ADULTES CAPABLES REQUIS POUR CETTE PROCÉDURE. SUIVEZ CET AVERTISSEMENT SOUS PEINE D'ENCOURIR DES BLESSURES GRAVES ET/OU DES DÉGÂTS MATÉRIELS.

DIESER VERFAHRENSSCHRITT MUSS VON ZWEI DAZU IN DER LAGE BEFINDLICHEN PERSONEN AUSGEFÜHRT WERDEN. EIN MISSACHTEN DIESER WARNUNG KANN ZU SCHWEREN VERLETZUNGEN UND/ODER SACHSCHÄDEN FÜHREN.

SE REQUIEREN DOS ADULTOS CAPACES PARA REALIZAR ESTE PROCEDIMIENTO. SI NO SE OBSERVA ESTA ADVERTENCIA SE PODRÍA OCASIONAR UNA LESIÓN GRAVE Y/O DAÑOS A LA PROPIEDAD.

