













<div><div><div><div><div><div></div><div>⚠ WARNING!</div></div></div><div><div><div>Read the Owners Manual and follow all warnings and instructions before using the helmet. For best protection, the helmet must be fitted and attached properly to the wearer's head. While this helmet provides significant protection, it cannot provide total protection from all foreseeable impacts. Please exercise care and good judgment whenever you ride and comply with all traffic regulations, so as to avoid accidents of any kind. This helmet should not be used when playing off of the bicycle. There is a strangulation hazard when using a helmet on playgrounds and climbing trees. A bicycle helmet is designed to absorb the energy of one significant impact (more than a minor scratch). If this occurs the helmet should be replaced or sent to the manufacturer for inspection. Velotec Sports generally recommends helmet replacement every three years.</div></div></div></div></div></div>	<div><div><div><div><div><div></div><div>CYCLIC™</div></div></div><div><div><div>BICYCLE HELMET OWNERS MANUAL</div></div></div></div><div><div><div>Thank you for your purchase!</div><div>Your new helmet was designed and manufactured with care. It went through numerous quality controls during the manufacturing process. The helmet passed all inspections and fulfills the requirements CPSC safety standard certification. This helmet is intended for pedal cycling. It is not designed for motor vehicle use or other sports. In order to protect you properly, your helmet must fit correctly and be worn correctly. To achieve a proper fitting helmet, do not use this product until you have read this manual completely and carefully, and understand the limitations of the product.</div></div></div><div><div><div><div><div><div></div><div>eyb™</div></div></div><div><div><div>cyclicsports.com</div></div></div></div></div></div></div></div>	<div><div><div><div><div><div>Fig 1: Fitting your helmet</div></div></div><div><div><div><div><div><div>CORRECT</div><div></div><div>INCORRECT</div><div></div><div><div>Too high on the head</div><div>Too low on the head</div></div></div></div></div></div></div></div></div></div>	<div><div><div><div><div><div>Fig 2: Adjusting the chinstrap</div></div></div><div><div><div><div><div><div></div><div></div></div></div><div><div><div></div><div></div></div></div></div></div></div></div></div></div>	<div><div><div><div><div><div>LED TAIL LIGHT</div></div></div><div><div><div>Your helmet is equipped with an LED rear light that can be used as desired to improve your visibility to others while riding. Please read all instructions and warnings prior to use.</div></div></div><div><div><div>USE OF THE TAIL LIGHT:</div><div>Before the first use, remove the plastic strip from the base of the light housing to enable the electrical contacts.</div></div></div><div><div><div>LIGHT FUNCTIONS:</div><div>The LED rear light has 3 light modes: Press once for chasing (energy saving) light mode Press twice for strobing (energy saving) mode Press once for continuous light mode Press again to turn off</div></div></div><div><div><div>REMOVAL AND ATTACHMENT OF THE TAIL LIGHT:</div><div>To remove the LED light, hold the top and bottom of the light housing with the thumb and index finger. Pull out firmly to detach from the helmet. To attach, simply locate the light in the helmet housing and push the light into place until it "clicks" and is secure.</div></div></div><div><div><div>CHANGING THE BATTERIES:</div><div>The helmet is supplied with (1) CR2032 coin cell battery. To change the battery, remove the light housing from the helmet as described above. Unscrew the two screws on the rear of the light with a small screwdriver. Open the black rear cover, and remove the white board inside the housing. Slide the battery out and exchange with a fresh battery. Replace the white board and put the rear cover back in place. Fasten the two screws and attach the light back onto the helmet.</div></div></div><div><div><div>Battery type: (1) CR2032 (available at most hardware and convenience stores)</div></div></div></div></div></div>	<div><div><div><div><div><div>INTENDED USE AND INSTRUCTIONS:</div><div>The LED light is intended to offer the rider better visibility. The light is not waterproof and should not be used in wet weather conditions. For best use, ensure the light is not obscured by jacket collars, scarfs or other articles that may block it's visibility. Check the light regularly and before each use for proper battery levels.</div></div></div><div><div><div>⚠ WARNING!</div><div>The helmet and light are not intended for use by children ages 14 or younger. The helmet and light are not a toy. Changing of batteries should only be performed by an adult. The light is intended to improve visibility and rider safety but cannot prevent accidental injury or death. Riding in dark or low light conditions is not recommended. Always check the battery level and light performance before use. Do not expose the light to excessive heat.</div></div></div><div><div><div>In the event the batteries are incorrectly replaced, there is a chance of an electrical short which may cause overheating or fire. Only replace the batteries with the same battery type. Dispose of batteries responsibly.</div></div></div><div><div><div>REPLACEMENT PARTS:</div><div>Replacement lights can be obtained by contacting customer service at service@velotecsports.com or 888-995-7437 (US and Canada).</div></div></div></div></div></div>	
<div><div><div><div><div><div>ALWAYS DO THE FOLLOWING:</div><div>Fasten the buckle and tighten the chinstrap so that it fits snug, but not too tight or too loose Check the adjustments on the straps and pads every time you wear your helmet Wear a helmet that is designed for the activity you are doing Wear the helmet so that it covers your forehead properly Inspect your helmet often for signs of wear, damage, and improper adjustment Replace your helmet if it shows signs of damage or wear Store your helmet in a cool and dry place Wear a helmet whenever your ride When cleaning your helmet, use mild soap and water Ride safely and use your common sense to stay within your limitations of skill and ability.</div></div></div></div></div></div>	<div><div><div><div><div><div>Adjust the strap so that it fits snug under the chin. When the strap is adjusted properly and buckled, it should hold the helmet firmly in place. The strap forms a "Y" under the ears, and must be closed under the jaw and on the side of the neck. Make sure the strap is back against the throat, and NOT placed on the point of the chin. If you open your mouth and feel a slight pressure from the chinstrap, the helmet fits well. Any slack in the strap must be pulled through the chin buckle. The loose ends of the strap must pass through the rubber "O" ring on the strap.</div></div></div><div><div><div>In order to adjust the position of the straps, hold one end of the chin buckle in one hand and slide the adjuster up or down the strap, as necessary to create a balanced and even "Y" shape under the ears. Check to ensure that the chinstrap is secure each time you put on your helmet. The chinstrap must be properly adjusted in order for the helmet to work. The strap is what keeps the helmet on your head.</div></div></div></div></div></div>	<div><div><div><div><div><div>Fig 3: Securing the chinstrap webbing</div></div></div><div><div><div></div><div></div></div></div></div></div></div>	<div><div><div><div><div><div>Fig 5: Using the Dial-to-Fit™ retention system</div></div></div><div><div><div><div><div><div>Tighten</div><div></div><div>Loosen</div><div></div></div></div></div></div></div></div></div></div>	<div><div><div><div><div><div>Fig 1: Removal of the light</div></div></div><div><div><div></div></div></div></div></div></div>	<div><div><div><div><div><div>Fig 2: Replacing the battery</div></div></div><div><div><div><div><div><div></div></div></div><div><div><div>Note: Screwdriver not included</div></div></div><div><div><div>Battery: (1) CR2032</div></div></div></div></div></div></div></div></div>	<div><div><div><div><div><div>⚠ WARNING!</div><div>KEEP BATTERIES OUT OF REACH OF CHILDREN. Swallowing may lead to serious injury in as little as 2 hours or death due to chemical burns and potential perforation of the oesophagus. If you suspect your child has swallowed or inhaled a coin cell battery, seek medical attention immediately. Always examine devices and make sure the battery compartment is securely screwed closed. Do not use if the compartment is not secure. Dispose of used batteries immediately and safely. Dead batteries can still be dangerous. Tell others about the risks associated with coin cell batteries and how to keep their children safe.</div></div></div></div></div></div>